Investigating Solar Energy Teacher Guide

INVESTIGATIVE QUESTION: What is the effect of using different light sources to power simple appliances with a solar cell?

In this activity your students will:

- 1. Observe the transfer of solar energy (light energy) to different appliances with a solar cell.
- 2. Investigate the effect of using different solar sources to supply energy to appliances.

Your students will work in groups of 4. Each group will be given two solar panel kits. Divide each group into teams of two. Each team will use one solar panel for 1/2 of the class period and switch panels at the midway point.



Step 1: Tools to Capture Solar Energy

Inside your Solar Kit you will find many pieces. Read the descriptions of each component below.





Step 2: Setting up your equipment:

- 1. Each group has two solar cells. In teams of 2 they will first experiment with one solar cell circuit. After all observations are made for the first series of experiments, students will switch to a new solar cell circuit.
- 2. One solar cell is prewired to power the light bulb and fan motor appliance. The other solar cell is prewired to power the music unit. Use the pictures below to select the correct solar cell set up.





- 1. Turn your solar cell panel over. Be sure it is wired as shown in the picture above. This is a **parallel** connection. This pattern increases the electrical current (Amperes) to the appliance.
 - a. Positive poles are connected to positive poles. Positive (+) pole 2 is connected to the next positive (+) pole 4 with a connecting wire. Positive (+) pole 4 is connected to positive (+) pole 6.
 - Negative poles are connected to negative poles. Negative (-) pole (1) is connected to negative (-) pole 3. Negative (-) pole 3 is connected to negative (-) pole (5).
- 2. Connect your appliance.



a. Look at the **appliance** you will be using. The wire splits in two. There are two separate connection terminals.

- b. Unscrew the screw nuts at points 1 and 2.
- c. Place a connection terminal on the end of the wire over **pole 1**.
- d. Place a connection terminal on the end of the wire over **pole 2**.
- e. Replace and tighten the screw nut. Be sure it is just tight enough to make a connection. **If you make it too tight it will break the solar panel**.
- 3. Continue to Step 3: Conducting The Experiment.

b. **Music Box Wiring (4.5V 100mA system)**:



- 1. Turn your solar cell panel over. Be sure it is wired as shown above. This is a **series** connection. This pattern increases **Voltage**.
 - a. The **positive (+) pole 2** is connected to **negative (-) pole 3** with a connecting wire. **Positive (+) pole 4** is connected to **negative (+) pole 5**.
- 2. Connect the Music Box.



a. The Music box requires special wiring. The wire splits into two connection terminals. One connection terminal is marked with a + label or is colored red. The other connection terminal is **unmarked**.

The wire with a + label and is colored red attaches to a **positive (+) pole**. The unmarked wire to a **negative (-) pole**.

- b. Unscrew the screw nuts at points 1 and 6.
- c. Place the (+) and red connection terminal on the end of the wire over positive (+) pole
 6.
- d. Place the *unmarked* connection terminal over **negative** (-) **pole 1**.
- e. Replace and tighten the screw nuts. Be sure it is just tight enough to make a connection. **If you make it too tight it will break the solar panel**.
- 3. Panel Stand Assembly

If you would like to use the panel stand follow these steps:

- A. Slide the slot on the Neck over the Ridge on the base. B. Click assembly into place.
- a. Assemble stand base and neck.



b. Connect Base and Neck to Panel

c. Assembled Panel and Stand: Adjust the angle by loosening and tightening screws at the panel or base connections.



4. Continue to Step 3: Conducting the experiment.

Step 3: Conducting the experiment:

Basic Set Up:

- 1. For the first half of the class work with solar kit 1. At midway point switch to solar kit 2.
- 2. You will be using 3 different light sources in this experiment.
 - a. Direct artificial light (gooseneck Lamp with 100 watt bulb)
 - b. Sunlight (direct sunlight or near a bright window using **natural light**)
 - c. Normal room lighting
- 3. Place your solar panel near your light source.
 - a. When using the direct artificial light it is important to start with the light 5 inches away from the solar panel. Closer positioning could damage the panel. See below.



- 4. Change your light source conditions.
 - a. As you change your light source think about the following questions: What happens? How does the appliance's performance change? Does it slow down or speed up? Is it louder or quieter? When does your appliance stop working?
 - b. Try using each appliance under different light sources.
 - c. Increase and decrease the distance between your light source and your solar panel.
 - d. Block the light source completely.
- 5. Instruct students to complete the **Investigating Solar Energy: Observations Sheet.**

7